

USER INSTRUCTION MANUAL





Do not skip this instruction manual. Read the instruction manual carefully before using the equipment. If failed in doing so it may cause serious Injury or Death.

Manufacturer : SAFE KEEPER, 314 E, CANAL ST, MULBERRY, FL 33860

Certification Body : SATRA Technology Centre, Wyndham Way, Telford Way,

Kettering, NN16 8SD, UK (Notified Body 0321)

Ongoing Assessment Body : SGS United Kingdom Ltd., Unit 202B, Worle Parkway.

Weston-super-Mare, BS22 6WA, UNITED KINGDOM (Notified Body 0120)

This manual must be read and understood in its entirety and used as part of fall protection training program as required by OSHA or any state regularity agency. These instructions are intended to meet the manufacturer instructions as required by ANSI 7359 1-2007 and OSHA. The user must fully understand the proper equipment use and limitations.

TECHNICAL SPECIFICATIONS:								
Ref. No.	Product Name	Minimum Breaking System	Material of Construction	Complying Norm				
SA01-SK	Hinged Steel Roof Anchor (Reusable)	5000 lbs / 23 kN	Galavanized Steel with Stamped D-Ring	ANSI Z359.1-2007				

1. GENERAL REQUIREMENTS, WARNINGS AND LIMITATIONS:

- The Equipment is designed for use as a part of a personal fall protection system. Components must not be used
 for any other operation other than that which it has been designed and approved. Fall Arrest system are designed
 to comply with OSHA. Fall Restraint System must be designed by a Qualified Person, and must be installed and
 used under the supervision of a competent person.
- All authorized persons/users must refer the regulations governing occupational safety, as well as applicable
 ANSI or CSA standards. Please refer to product labeling for information on specific OSHA regulations, and ANSI
 and CSA standards met by product.
- Consult a doctor if there is any reason to doubt a user's ability to withstand and safely absorb fall arrest forces.
 Age, fitness, health conditions can seriously affect the worker in case a fall occurs. Pregnant Women and minors should not use this equipment.
- Proper precautions should always be taken to remove any obstructions, debris, material, or other recognized
 hazards from the work area that could cause injuries or interfere with the operation of the system. All equipment
 must be inspected before each use according to the manufacturer's instructions, by a qualified person on a
 regular basis
- All equipments must be regularly inspected by a competent person & must be checked before each use.

1. GENERAL REQUIREMENTS, WARNINGS AND LIMITATIONS:

- The Equipment is designed for use as a part of a personal fall protection system. Components must not be used
 for any other operation other than that which it has been designed and approved. Fall Arrest system are designed
 to comply with OSHA. Fall Restraint System must be designed by a Qualified Person, and must be installed and
 used under the supervision of a competent person.
- All authorized persons/users must refer the regulations governing occupational safety, as well as applicable
 ANSI or CSA standards. Please refer to product labeling for information on specific OSHA regulations, and ANSI
 and CSA standards met by product.
- Consult a doctor if there is any reason to doubt a user's ability to withstand and safely absorb fall arrest forces.
 Age, fitness, health conditions can seriously affect the worker in case a fall occurs. Pregnant Women and minors should not use this equipment.
- Proper precautions should always be taken to remove any obstructions, debris, material, or other recognized
 hazards from the work area that could cause injuries or interfere with the operation of the system. All equipment
 must be inspected before each use according to the manufacturer's instructions, by a qualified person on a
 regular basis.
- All equipments must be regularly inspected by a competent person & must be checked before each use.


- To minimize the potential for accidental disengagement, a competent person must ensure system compatibility.
- Equipment must not be altered in any way. Repairs must be performed only by the Manufacturer, or persons
 entities authorized in writing by the manufacturer.
- Any product exhibiting deformities, unusual wear, or deterioration must be immediately discarded. Any
 equipment subject to a fall must be removed from service. The authorized person/user shall have a rescue plan
 ready and the means at hand to implement it when using this equipment.
- Never use fall protection equipment for purposes other than those for which it was designed. Fall protection
 equipment should never be used for towing or hoisting.
- All synthetic material must be protected from slag, hot sparks, open flames, or other heat sources. The use of heat resistant materials is recommended in these applications.
- Never use natural materials (manila, cotton, etc.) as part of a fall protection system.
- Do not expose this equipment to chemicals which may have a harmful effect on the materials used to construct
 it. Be especially aware of caustic environment, or those that contain high levels of organic acids or bases. If you
 are uncertain about the safe operation of this equipment in any environment, contact Safe Keeper for further
 instructions.
- Do not use the equipment near sharp edges, abrasive surfaces and looping around small diameter structural members.
- Do not use the equipment around moving machinery or electrical hazards.
- Safe Keeper Steel Anchors should be used only with the combinations of components, sub-systems or both which
 may affect or interfere with the safe function of

one another. Be certain that connecting devices are compatible and that other elements of the PFAS are safe and compatible before use.

2 SYSTEM LIMITATIONS & REQUIREMENTS:

Consider the following limitations/requirements prior to installing or using this equipment:

- CAPACITY: Safe Keeper Steel Anchors are designed for use by ONE person with a combined weight (clothing, tools, etc.) of not more than 310 lbs. (140 kg) Make sure all of the components in the system are rated to a capacity appropriate to the application. All Safe Keeper Steel Anchors are rated 5000 lbs. (23kN).
- FREE FALL: Personal fall arrest systems used with this equipment must be rigged to limit the free fall to 6 feet (1.8 M) as per ANSI Z359.1.Restraint systems must be rigged so



- Connecting Subsystem (Energy Absorbing Lanyard Shown)
- B Working Level
- C Lower Level or Obstruction
- **D** Free Fall 6ft. (1.8m) Max. (per ANSI Z3559.1)
- E Deceleration Distance
- F Total Fall Distance Free Fall (D) + Deceleration (E)

3 MOVEMENT OF HARNESS ATTACHMENT FLEMENT:

SWING FALLS: Swing falls occur when the anchorage point is not directly above the point when a fall occurs. The force of striking an object in a swing fall may cause serious injury or death. Minimize swing falls by working as close to the anchorage point as possible. Do not permit a swing fall if injury could occur. Swing falls will significantly increase the clearance required when a self-retracting lifeline or other variable length connecting subsystem is used.



4. ENVIRONMENTAL HAZARDS:

Use of this equipment in areas with environmental hazards may require additional precautions to prevent injury to the user or damage to the equipment. Hazards may include, but are not limited to; heat, chemicals, corrosive environments, high voltage power lines, gases, moving machinery and sharp edges.

5 COMPATIBILITY OF COMPONENTS:

Unless otherwise noted, Safe Keeper equipment is designed for use with Safe Keeper approved components and subsystems only. Substitutions or replacements made with non-approved components or subsystems may jeografize compatibility of equipment and may affect safety and reliability of the complete system.

- COMPATIBILITY OF CONNECTORS: Connectors are considered to be compatible with connecting elements when they have been designed to work together in such a way that their sizes and shapes do not cause their gate mechanisms to inadvertently open regardless of how they become oriented. If the connecting element that a snap hook or carabiner attaches to is undersized or irregular in shape, a situation could occur where the connecting element applies a force to the gate of the snap hook or carabiner. This force may cause the gate (of either a self-locking or a non-locking snap hook) to open, allowing the snap hook or carabiner to disengage from the connecting point. Connectors must be compatible in size, shape, and strength. Self-locking snap hooks and carabiners must comply to ANSI 2359.1 and OSHA.
- Making Connections: Always use snap hooks and carabiners which needs double manual action to open with
 this equipment. Only use connectors that are suitable to each application. Ensure all connections are compatible
 in size, shape and strength. Do not use equipment that is not compatible. Ensure all connectors are fully closed
 and locked the connection should not be made-
 - To a D-ring to which another connector is attached.
 - In a manner that would result in a load on the gate.
 - In a false engagement, where features that protrude from the snap hook or carabiner catch on the anchor and without visual confirmation seems to be fully engaged to the anchor point.
 - To each other
 - Directly to webbing or rope lanyard or tie-back (unless the manufacturer's instructions for both the lanyard and connector specifically allow such a connection).
 - To any object which is shaped or dimensioned such that the snap hook or carabiner will not close and lock, or that roll-out could occur.

Note: Other than 3,600 lb. (16 kN) gated hooks, large throat opening snap hooks should not be connected to standard size D-rings or similar objects which will result in a load on the gate if the hook or D-ring twists or rotates. Large throat snap hooks are designed for use on fixed structural elements such as rebar or cross members that are not shaped in a way that can capture the gate of the hook.

6. RESTRICTIONS REGARDING MAKING CONNECTIONS:

- Do not make connections where the hook locking mechanism can come into contact with a structural member other equipment and potentially release the hook.
- Do not connect a snap hook into a loop or thimble of a wire rope or attach in any way to a slack wire rope.
- The snap hook must be free to align with the applied load as intended (regardless of the size or shape of the mating connector)
- A carabiner may be used to connect to a single or pair of soft loops on a body support such as a body belt or full body harness, provided the carabiner can fully close and lock. This type of connection is not allowed for snap hooks.
- A carabiner may be connected to a loop or ring connector that is already occupied by an automatic closing connector.


If the connecting element that a snap hook (shown) or carabiner attaches to is undersized or irregular in shape, a situation could occur where the connecting element applies a force to the gate of the snap hook or carabiner. This force may cause the gate (of either a self-locking or a non-locking snap hook) to open, allowing the snap hook or carabiner to disengage from the connecting point.

Unintentional Disengagement (Roll-Out) Small ring or other non-compatibly shaped element

Force is applied to the snan hook the connecting Ring.

The gate presses against 3. The gate opens allowing the connecting Ring. the snap hook to slip off.

Inappropriate Connections



7 CONNECTING SUB-SYSTEMS:

Personal fall arrest systems used with this equipment must meet applicable state, OSHA and ANSI requirements. A full body harness must be worn when this equipment is used as a component of a personal fall arrest system. As required by OSHA, the personal fall arrest system must be capable of arresting the user's fall with a maximum arresting force of 1,800 lbs. (8 kN), and limit the free fall to 6 ft. (1.8 m) or less. If the maximum free fall distance must be exceeded, the employer must document, based on test data, that the maximum arresting force will not be exceeded, and the personal fall arrest system will function properly. Free fall greater than 6 ft. (1.8 m), and up to a maximum of 12 ft. (3.7 m) is possible, Safe Keeper recommends using a personal fall arrest system incorporating a Safe Keeper Energy Absorbing Lanyard. Safe Keeper has performed testing using the Safe Keeper Energy Absorbing Lanyard in free falls up to 12 ft. (3.7 m) to ensure the maximum arresting force does not exceed 1,800 lbs. (8.0 kN), and the system functions properly.

8. RESCUE PLAN:

Rescue operation must be performed by a trained and competent personnel. The rescue operation must be performed under the supervision of the rescue expert team or personal. It is advised that while working on site, work in pairs. Before going for the work the user must have the rescue plan ready according to the work.

If Equipment Is Subjected To A Fall-Remove the equipment from service immediately if it has been subjected to the forces of a fall arrest. Contact your distributor or Safe Keeper about policies regarding replacement of Safe Keeper components involved in a fall.

9 SPECIFIC INSTRUCTIONS:

Safe Keeper Anchors are designed to provide complete attachment system to the user in the event of a fall. These attachment systems must be connected to the proper body support and connecting facility. These Anchors are meant to hold the victim of fall till the rescue operation is performed, so this is important that the whole system must have all the essential components before going for use. The whole fall arrest system must be used by a trained/competent person. It is advisable to make a checklist of the essential components according to one's use before going for work.

10. USE OF FALL ARREST SYSTEM:

The fall arrest system MUST ONLY be connected to the back attaching element on the harness provided for the purpose ("D" ring or webbing attachment extension) or to the chest anchorage points ("webbing link" or "D" link). The chest anchorage points must imperatively be used together. The D-rings on the belt and the ventral anchorage point must only be used for the attachment of a work positioning or retaining system and never with a fall arrest system.

During use, check regularly the adjustment and/or attachment points.

11. INSPECTION:

Before each use, proceed with thorough visual examination to ensure that the PPE is intact (the same applies for the equipment used with the harness (connectors, lanyard...) and take all necessary steps concerning the implementation of rescue in total safety. In the event of your product being contaminated, consult the manufacturer or authorized agent. If you have any doubts regarding the safe state of the product or if the product has been used to arrest a fall, for your personal safety, it is essential to withdraw the PPE from service and send it back to the manufacturer or a qualified repair Center for checking or destruction.

Following the inspection, the center will provide written authorization or refusal for the use of the PPE. Never attempt to modify or renair PPF

Before each use of this equipment inspect it according to the following guidelines: A formal inspection of fall protection products/components must be performed at least every six months by a competent person other than the user. The frequency of formal inspections should be based on conditions of use or exposure. Record the inspection results in the inspection and maintenance log at the end of this manual. The component should be checked for Cut, Frayed, Heavily Soiled, Welding Burns etc. Metal parts like D-rings should be duly checked for cracks, bents, deformities, corrosions etc.

12 INSTRUCTIONS FOR INSTALLATION & USAGE

SA01-SK

This Hinged Steel Roof Anchor is designed to be used as a temporarily installed anchorage connector on wooden frame structures

- Spread the anchor base legs apart to match the surface it will be mounted on, either a roof peak or flat surface.
- Position the anchor on the roof such that the nailing holes along with the center of the legs are over a framing member
- Push down the anchor to but the legs over the surface and insert the supplied nails.

The Anchor can be fixed so that the load impact is in the directions shown in the figure below :-



- 13. ANCHORAGE STRENGTH: The Anchorage strength required depends on the application type. The following are the requirements of ANSI 359.1 for these application types:-
 - ANCHORAGE & ANCHORAGE STRENGTH: Anchorage and anchorage strength requirements are dependent on the full body harness application. In accordance with ANSI Z359.1, anchorages selected for Fall Arrest Systems must meet the anchorage strength requirements defined in below Table.

Table - Anchorage Strength Requirements						
Fall Arrest ¹	Non-Certified Anchorage:	5,000lbs (23 kN)				
rali Allest	Certified Anchorage?	2 Times the Maximum Arresting Force for Certified Anchorage				
Restraint ¹	Non-Certified Anchorage	1,000 (4,5 kN)				
nestraint	Certified Anchorages ²	2 times the foreseeable force for certified anchorages.				
Work Positioning ¹	Non-Certified Anchorages	3,000 lbs (13.3 kN)				
Work i ositioning	Certified Anchorage ²	2 times the foreseeable force for certified anchorage.				
Rescue ¹	Non-Certified Anchorage	3,000 lbs (13.3 kN)				
nescue	Certified Anchorage ²	5 times the foreseeable force for certified anchorage.				
Climbing	The structure which a climbing system is attached must sustain the loads required by that particular system. See the instructions for the climbing system for requirements.					

- 1 Multiple Systems: When more than one of the defined system is attached to an anchorage, the strength defined for Non- Certified or certified anchorage shall be multiplied by the number of systems attached to the anchorage.
- 2 Certified Anchorage: An anchorage for fall arrest, positioning, restraint, or rescue systems that a qualified person certifies to be capable of supporting the potential fall force that meet the criteria for a certified anchorage prescribed in this standard.

- Fall Arrest: Anchorages selected for fall arrest systems shall have a strength capable of sustaining static loads applied in the directions permitted by the system of at least: 1.5,000 lbs. (23 kN) for non-certified anchorages, or 2. Two times the maximum arresting force for certified anchorages. When more than one fall arrest system is attached to an anchorage, the strengths set forth in (1) and (2) above shall be multiplied by the number of systems attached to the anchorage.
- As Per OSHA: Anchorages used for attachment of personal fall arrest systems shall be independent of any
 anchorage being used to support or suspend platforms and capable of supporting at least 5,000 lbs.(23 kN) per
 user attached, or be designed, installed and used as part of a complete PFAS which maintains a safety factor of
 at least two, and is under the supervision of a qualified person.
- Work Positioning: The structure to which the work positioning system is attached must sustain static loads
 applied in the directions permitted by the work positioning system of at least 3,000 lbs., or twice the potential
 impact load, whichever is greater. See OSHA. When more than one work positioning system is attached to an
 anchorage, the strengths stated above must be multiplied by the number of work positioning systems attached
 to the anchorage.
- Restraint: Anchorages selected for restraint and travel restraint systems shall have a strength capable of
 sustaining static loads applied in the directions permitted by the system of at least: 1. 1,000 lbs. (4.5 kN) for
 non-certified anchorages, or 2. Two times the foreseeable force for certified anchorages. When more than one
 restraint and travel restraint system is attached to an anchorage, the strengths set forth in (1) and (2) above
 shall be multiplied by the number of systems attached to the anchorage.
- Rescue: Anchorages selected for restraint and travel restraint systems shall have a strength capable of
 sustaining static loads applied in the directions permitted by the system of at least: 1. 3,000 lbs. (13.3 kN) for
 non-certified anchorages, or 2. Five times the foreseeable force for certified anchorages. When more than one
 restraint and travel restraint system is attached to an anchorage, the strengths set forth in (1) and (2) above
 shall be multiplied by the number of systems attached to the anchorage.
- Fall clearance: If there is a risk of fall or if the only anchorage is below the attachment points on the harness, it is
 essential to use a lanyard provided with an energy absorber. Before using a shock-absorbing lanyard, check
 that there is sufficient fall clearance below the user to prevent any collision with the structure or the ground.

14 PERIODIC EXAMINATION:

Keep these instructions with the product and fill in the identification sheet, entering the information taken from the markings.

- The periodic examination is essential to test the resistance and condition of the equipment and to guarantee the safety of the user.
- A qualified person must examine this equipment at least once each year in strict compliance with the instructions
 of the manufacturer and the previous check must be recorded on the attached sheet.
- The frequency of inspection should be increased in accordance with the regulations, if the equipment is in heavy usage or if the equipment is used in harsh environments. Also check that the markings are legible.

15. MATERIAL & CONSTRUCTION

Material: Galvanized Steel, Stainless Steel.


16. SYSTEM REQUIREMENTS:

- Compatibility of Components: Safe Keeper Fall Protection equipment is designed to be used with Safe Keeper approved components. Please contact Safe Keeper if you have a question regarding compatibility. Making substitutions without approval from Safe Keeper Fall Protection may lead to injuries and or death by compromising the safety and reliability of the complete system. A Qualified person can make a determination on compatibility of equipment from different manufacturers.
- Compatibility of Connectors: Connectors (D-rings, hooks, carabiners) must be capable of supporting at least 5,000 lbs. (23 kN). Do not use equipment that is not compatible. Non-compatible connectors may unintentionally disengage. Self-locking snap hooks and carabiners are required by CSA, ANSI and OSHA. Connectors must be compatible in size. shape, and strength.
- Making Connections: Only use self-locking snap hooks and carabiners with any Safe Keeper Fall Protection
 equipment. Do not use equipment that is not compatible.

17 OTHERS:

- Maintenance & Cleaning: Repairs to equipment can be made only by a Safe Keeper representative or person or
 entity authorized by Safe Keeper. Contact Safe Keeper for maintenance and repair. Cleaning after use is important for
 maintaining the safety and life of the equipment. Cleanse the equipment of all dirt, corrosives, and contaminants.
 If the equipment cannot simply be wiped clean, use a mild soap and water. Rinse, wipe, and hang to dry in shade.
- STORAGE: Store the anchorage connector component in a cool, dry and clean place out of direct sunlight. Avoid areas where heat, moisture, light, oil, and chemicals or their vapors or other degrading elements may be present. Equipment which is damaged or in need of maintenance should not be stored in the same area as usable equipment. Heavily soiled, wet, or otherwise contaminated equipment should be properly maintained (e.g. dried and cleaned) prior to storage.
 - Prior to using equipment which has been stored for long periods of time, a Formal Inspection should be performed by a competent person. For harnesses with Dielectric buckles, pass-thru buckles or Quick Connect Buckles. store the harness with the buckles connected.
- TRAINING: It is the responsibility of the users to ensure that they read, understand, and follow all instructions and
 are trained in the care and use of this device. Training should be repeated periodically and any time there is a
 change of components within the system. Training must be conducted without exposing the trainee to a fall
 hazard
 - As Per OSHA: Anchorages used for attachment of personal fall arrest systems shall be independent of any
 anchorage being used to support or suspend platforms and capable of supporting at least 5,000 lbs.
 (23kN) per user attached, or be designed, installed and used as part of a complete PFAS which maintain a
 safety factor of at least two, and is under the supervision of a qualified person.

18 MARKING.



WARRANTY: All Safe Keeper products bear 1 year warranty against manufacturing defects, applicable on Unused Safe Keeper products, from the date of purchase. However, Safe Keeper shall not be liable for any accident or damage while the product is in use

LIFESPAN: The estimated product lifespan of this product is 10 years from the date of manufacturing. The following factors can reduce the lifespan of the product: intense use, contact with chemical substances, specially aggressive environment, extreme temperature exposure. JV exposure, abrasion, cuts, violent impacts, bad use or maintenance.

DISCLAIMER: This information on the product is based upon technical data that Safe Keeper obtained under laboratory conditions and believes to be reliable. Safe Keeper does not guarantee results and takes no liability or obligation in connection with this information. As conditions of end use are beyond our control it is the user's responsibility to determine the hazard levels and the use of proper personal protective equipment. Persons having technical expertise should undertake evaluation under their own specific end-use conditions, at their own discretion and risk. Please ensure that this information is only to check that the product selected is suitable for the intended use. Any product that is damaged, torn, worn or punctured should be immediately discontinued from usage.

		EQUIPMENT RECORD)		
Product					
Model & type/Identification		Trade Name		Identification number	
Manufacturer		Address		Tel, email into use	
Year of manufacture		Purchase Date		Date first put into use	
Other relevant i	information (eg. document num	iber)		!	
	PERIODI	C EXAMINATION AND R	EPAIR HISTORY		
Date	Reason for entry (periodic examination or repair)	Defects noted, repairs carried out and other relevant information	Name and signature of competent person		Periodic examination next due date



SAFE KEEPER, 314 E. CANAL ST. MULBERRY, FL 33860