

Installation Instructions

- 1. All gutters to be fitted with GutterFoam should be thoroughly cleaned out.
- 2. All downspouts should be cleared of any obstruction, especially where there are elbows.
- 3. Insert GutterFoam into the gutter so that its narrowest point, (the sharpest angle) is tucked under the front lip of the gutter. GutterFoam should run to the back of the gutter completely filling the space across the top of the gutter then turn at a 90° angle to sit snugly on the bottom of the gutter.

4a. Over the hangers



Make a cut into the foam so the foam can straddle the strap. The cut will start on the bottom of the foam and cut up towards the top without cutting all the way through the foam. You will only make your vertical cut into the foam as far as you need to have the foam straddle the gutter hanger. The gutter hanger will fit nicely into the cut.

4b. Under the hangers

Slide GutterFoam into the gutter under each spike or hanger, then tuck the front edge of the material under the lip of the gutter. Place the material sections into the gutter one piece after another making sure there are no gaps between sections. Miter the corners when gutters make a change in direction.



5. Do not stretch the material to make it fit as it will shrink back to its original form and leave gaps.

Detailed instructions, pictures, and videos can be found on our website: www.gutterfoam.com

